



MINI PRINTER USER MUNUAL  Please read the instruction manual carefully before using this product	Thank you for choosing our printer! For a better user experience,we strongly recommend that you read our user manual before using the product!. Product Appearance  Indicator Light Description 1.If you turn on the printer without Bluetooth connection, the button light will constantly changing from dark to bright. 2.If you turn on the printer normally,the light button will steady on green. 3.If the printer is lacking of paper,the green light will flash. 4.If the printer head is overheating,the light button will steady on red,please wait 5 minutes before the next printing. 5.If the battery is too low,the red light will flash,please charge the printer in time.	Usage Guidelines ① Download the "Funny Print" APP Method 1 Open "APP Store", search "Funny Print" APP and download it.  Method 2 Open the "Google Play " directly and search "Funny Print" APP and download it.  Method 3 The "Funny Print" APP QR code will be printed automatically when you double-click the button after turned on the printer, you also can download it by scan the QR code on the paper. ②Usage Steps Tips: Please fully charge the printer for the first time, then unplug the charger before use! ① Please press the button and hold on for 3 seconds to turn on the printer! 
--	--	--